

Safe-T-View Egress Window Well Custom Cover

Installation instructions for Concrete and Timber Window Wells

1. Carefully un-wrap your new Safe-T-View Cover without the use of a box cutter to ensure not damaging the XL

polycarbonate. Please contact your local recycling center for responsible disposal of the cardboard packaging.


Position the cover over the window well opening to determine placement of the

side tube mounts for each side. Remove the cover to mount the side tubes in holes provided*. Position and install the front tube mount on the "face" of the areawall. Use multi-

purpose exterior grade screws. For concrete areawalls, predrilling screw holes will be required.




3. Re-position the cover over the window well and simply Squeeze-n-Size[™] the pre-installed spring clips to the correct width dimension on each side and then lower the cover to adjust the clips over the front tube mount. Hand adjustments






4. Attach the safety retainerhinge lanyards via the front screw holes in the side tube



5. Peel back the protective film from the UV protected polycarbonate to enjoy the clearest view available from any



Safe-T-View[™] Limited Lifetime Warranty

St Paul Corrugating, ("SPC") warrants Safe-T-View™ Cover window well for the original purchaser for a lifetime against breakage due to defects in materials or workmanship. Further warranted for a period of ten (10) years from the date of purchase for excessive yellowing or discoloring of the XL polycarbonate. Warranty applies to Covers that are used for their intended purposes only. and are maintained by the purchaser in accordance with the instructions provided with each Cover. Please contact us for the complete details on this unique warranty.

Maintenance & Cleaning

Safe-T-View™ Covers should be inspected and cleaned periodically. Check cover(s) regularly to see that it has not shifted or moved from its properly installed position. Covers should be kept clean to eliminate the build up of hard water spots. Hard water deposits can cause discoloration that is not covered under the warranty. Any broken or missing parts should be repaired or replaced immediately.

St. Paul Corrugating Co, Inc.

email: info@stpaulcorrugating.com website: www.stpaulcorrugating.com 700 39th Ave NE Minneapolis MN 55421 Toll free: 1-800-439-9271

